


Hustler® Parts Manual



200 South Ridge Road

Hesston, Kansas

67062



NOTICE OF REQUIREMENT OF SPARK ARRESTER MUFFLER

This equipment may create sparks that can start fires around dry vegetation. California Public Resources Code Section 4442.6 provides that it is unlawful to use or operate an internal combustion engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester maintained in effective working order. A spark arrester is a device constructed of nonflammable materials specifically for the purpose of removing and retaining carbon and other flammable particles over 0.0232 of an inch in size from the exhaust flow of an internal combustion engine that uses hydrocarbon fuels or which is qualified and rated by the United States Forest Service. Other states or federal areas may have similar laws. The Operator Should Contact Local Fire Agencies For Laws or Regulations Relating to Fire Prevention Requirements. THIS EQUIPMENT DOES NOT HAVE A SPARK ARRESTER AND YOU SHOULD CONTACT YOUR AUTHORIZED DEALER FOR THE PURCHASE OF A SPARK ARRESTER.

Inspect spark arrester daily; replace every 500 hours or as needed.

The Engine Owner's Manual provides information regarding the U.S. Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance and warranty.

Keep Engine Owner's Manual with your unit. Should the Engine Owner's Manual become damaged or illegible, replace immediately. Replacements may be ordered per the information found in the Product Information section of the owner's manual.

Federal law and California State law prohibit the following acts or the causing thereof:

- 1. The removal or rendering inoperative by any person other than for purposes of maintenance, repair, replacement, of any device or element of design incorporated into any equipment for the purposes of emissions control prior to or after its sales or delivery to the ultimate purchaser or while it is in use, or**
- 2. The use of the equipment after such device or element of design has been removed or rendered inoperative by any person.**

General Information	1
Frame, Instrument Panel, Wire Harness, Battery & Engine Guard	
Frame	3-1
Fenders, Instrument Panel & Wire Harness	3-2
Engine Guard	3-3
Battery	3-4
Transmissions, Drive Belt, Steering & Brake	
Transmission Assembly & Drive Belt (Multi-Page)	4-1
Transmission Service Parts	4-2
Steering & Brake	4-3
Steering Cover Assembly	4-4
Wheels & Tires	
Wheel & Tire	5-1
Front Wheel Assembly Breakdown	5-2
Drive Wheel Breakdown	5-3
Engine, Muffler, Clutch & Fuel System	
Engine, Muffler & Clutch (Multi-Page)	6-1
Engine Service Parts	6-2
Fuel System	6-3
Fuel Tank Service Parts	6-4
Deck, Deck Belt, Blades & Deck Lift	
Service Deck	7-1
Deck Pulleys & Spindles	7-2
Spindle Service Parts - 604214	7-3
Deck	7-4
Deck Lift	7-5
Seat	
Seat	8-1
Seat Service Parts	8-2

General Information

Note: When ordering parts, you must use the part number as shown for each part, not the index number. Always give the model and serial number to your parts and service representative.

Note: Items sold in bulk such as seals and hoses are sold by the foot.

Using This Manual

This manual is part of a service package for the Hustler® mowers. Use of this manual in conjunction with other Hustler® mower and component manuals will provide the information necessary to service and maintain Hustler® mowers.

This Parts Manual provides a complete parts listing for the unit. Use this manual when ordering parts. Illustrations used were current at the time of printing, but subsequent production changes may cause your machine to vary slightly in detail. Excel Industries, Inc. reserves the right to redesign and change the machine as deemed necessary, without notification. If a change has been made to your machine which is not reflected in this parts manual, see your authorized dealer for current information and parts.

The Service Manual is a service guide for use by Service Technicians. It provides the necessary information needed to perform normal maintenance requirements on these units.

The Operator's Manual provides fundamental operational information and operational safety that is needed when operating the mower.

The component manuals are furnished by the various manufacturers to be used for the troubleshooting and servicing of their products.

Hardware Description Codes & Abbreviations

The following codes are used throughout this parts manual. Refer to this list when ordering parts.


ABBREVIATION	DESCRIPTION	ABBREVIATION	DESCRIPTION
CB	CARRIAGE BOLT	MB	MACHINE BUSHING
CE	CLEVIS PIN	MS	MACHINE SCREW
CN	CLIP NUT	NT	NUT
CP	COTTER PIN	SC	SELF TAPPING CAP SCREW
CS	CAP SCREW	SH	SOCKET HEAD
CW	CUP WASHER	SB	SHOULDER BOLT
FDRW	FENDER WASHER	SS	SET SCREW
FW	FLAT WASHER	OD	OUTSIDE DIAMETER
HX	HEX HEAD	ID	INSIDE DIAMETER
LW	LOCK WASHER	WN	WELD NUT

Standard Torques

The following chart lists the standard torque values for the threaded fasteners found in this manual. Torque all cap screws, nuts and set screws to these values unless a different torque is shown in the Notes section next to the fastener.

SIZE	FT-LBS	N•M	SIZE	FT-LBS	N•M
.250	8.2	11.1	M3	1	1.3
.312	17	23	M4	2.2	3
.375	30	40	M5	4.5	6.1
.438	48	65	M6	7.7	10.4
.500	73	99	M8	18.5	25
.562	105	143	M10	37	50
.625	145	200	M12	64	87
.750	260	350	M14	80	108.5
.875	420	565	M16	160	215
1.00	625	850	M20	320	435
			M24	555	750


Cette page intentionnellement laissée vierge



Élément	Numéro de pièce	Qté	Nom
1	123637-3	1	SEAT SUPPORT, RSD
2	029629	6	CS .375-16X0.75 HXF G5ZY
3	123636-3	1	SPRING SUPPORT, RSD
4	553148	1	SERVICE, BUMPER STAMPED
Not Shown	551857	1	SVC, BUMPER
5	602041	1	DECAL, HOT
6	604176	30	CS .375-16X.75 HXF NF
7	551858	1	SVC, ENGINE PLATE
8	029751	4	CS .375-16X1.00 HXF G5ZY
9	551859	1	SVC, RS REAR BRKT
10	604177	30	NT .375-16 HXFLK PLN
11	016899	10	NT .375-16HXG5
12	551860	1	SVC, LS REAR BRKT
13	601982	5	CN .250-20X .150 MAX THK
14	551861	2	SVC, CROSS SUPPORT
15	551862	2	SVC, FRONT BRKT
16	551863	2	SVC, HYDRO BRKT
17	000331	6	WIRE TIE, SMALL/SHORT
18	604307	6	MOUNT, PUSH BUTTON
19	551865	1	SVC, FOOT PAN
20	119718	1	SVC, RS FRAME CHANNEL
21	551868	1	SVC, LS FRAME CHANNEL
22	551867	1	SVC, FRONT CROSS FRAME
23	552570	1	BATTERY TRAY
24	N/A	1	SERIAL NUMBER / SPEC DECAL
25	601967	1	DECAL, ENGINE COMPART
26	794834CE	1	CE 100 DBA LIMIT DECAL
27	776310	1	DECAL, CE MARK
28	605782	1	DECAL, LEVEL FUEL BLOWM
29	601981	1	DECAL, SAFE OPERATE-GRAY

Comments for Page: Frame

1. In the event the serial number tag becomes damaged or illegible, please contact your dealer to order a replacement.
2. 553148 is used on mowers S/N 16050225 & higher. 551857 is used on mowers S/N prior to 16050225.
3. The engine plate, foot pan and LS frame channel include decals.




Fenders, Instrument Panel & Wire Harness

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	601097	1	CABLE, CHOKE
2	776476	1	SWITCH, PTO 6201-321
3	785808	1	KEY ASSEMBLY
4	551898	1	SERVICE, INSTR PANEL
5	604196	1	DECAL, INST PANEL
6	045898	1	IGNITION SWITCH
7	055939	1	CS .250-20X0.75 HX G5 ZY
8	601098	2	CB 10-24 X .500 ZYNC
9	704932	2	FW 0.219X.50X.05 ZY
10	059832	2	NT #10-24 HX NL ZN
11	601096	1	CABLE, THROTTLE
12	604324	8	CS .250-20 X .75 HX FLG
13	552809	1	SVC, FENDER RS
14	552810	1	SVC, FENDER LS
15	601982	1	CN .250-20X .150 MAX THK
16	553505	1	SVC, FOOTREST
17	602407	1	DECAL, HUSTLER ID
18	029629	2	CS .375-16X0.75 HXF G5ZY
19	016899	2	NT .375-16HXG5
20	000331	2	WIRE TIE, SMALL/SHORT
21	604388	2	DECAL, RAPTOR FENDER
22	114052	1	KIT, CLUTCH CONN. REP.
23	601053	2	RELAY, SEALED W/BRACKET
24	604876	1	WIRE HARNESS

Comments for Page: Fenders, Instrument Panel & Wire Harness


1. The instrument panel and fenders include decals.
2. The sealed relay includes a bracket.



Engine Guard

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	122817	1	KIT, ENGINE GUARD
Commentaires pour le numéro de pièce 122817			
IMPORTANT - REFERENCE PRODUCT BULLETIN 571-R BEFORE ORDERING ENGINE GUARDNOTE: ENGINE GUARD KIT INCLUDES DECALS AND BOLTS.			
2	604745	1	DECAL, H LOGO, MFSD 36/4
3	029629	4	CS .375-16X0.75 HXF G5ZY
4	016899	4	NT .375-16HXG5
5	602041	1	DECAL, HOT




Battery

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC


Élément	Numéro de pièce	Qté	Nom
1	604178	1	STRAP, TIE DOWN
2	604465	2	CS .250-20X7.50 HX G5 ZC
3	768515	2	FW 0.281SAE
4	771428	1	BATTERY CBL BOOT-RED(FS)
5	024927	2	NT .250-20HXG5
6	029868	4	LW .250 INTEXT ZY
7	055939	2	CS .250-20X0.75 HX G5 ZY
8	000331	2	WIRE TIE, SMALL/SHORT
9	601982	2	CN .250-20X .150 MAX THK

Comments for Page: Battery

1. When performing service on the mower, disconnect the negative battery cable and do not reconnect it to the battery until ready to start the engine.



Élément	Numéro de pièce	Qté	Nom
1	710087	4	CS .312-18X2.500HXG5
2	604343	1	CB .375-16 X 2.25 STD ZN
3	043067	4	CS .312-18X3.000HXG5
4	016899	2	NT .375-16HXG5
5	607400	1	DRIVE BELT
6	080655	1	CS .375-16X1.500HXG5
7	767954	10	FW 0.379X.82X.06 HD ZY
8	604491	1	PULLEY, 2.0" IDLER
9	604490	1	SPRING, 3.00 X .50 EXT
10	005108	1	CS .375-16X3.500HXG5
11	116289	1	SPACER, PIVOT IDLER
12	116287	1	IDLER ARM
13	712893	1	FW 0.406X1.25X.12 HD ZY
14	086660	1	NT .375-16NLG8
15	054502	5	NT .375-16HXG5
16	706549	2	HP0.080X1.190
17	116218	2	LINK, TOW VALVE
18	768523	16	FW 0.343SAE
19	058776	8	NT .312-18NLG5
20	056036	4	CS .375-16X2.250HXG5
21	123634-3	1	CROSS BRACE, HYDROSTAT
22	604127	1	EZT, 19.2:1 TRANS
23	604128	1	EZT, 19.2:1 TRANS
24	116143	2	ROD, BRAKE ACTUATOR
25	768515	8	FW 0.281SAE
26	601051	2	OVERTRAVEL SPRING
27	068551	2	NT .250-20 HXZY NL
28	601131	2	SPRING, BRAKE ARM RET.




Transmission Assembly & Drive Belt (Multi-Page)


42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Comments for Page: Transmission Assembly & Drive Belt (Multi-Page)

1. Torque to 23 N•m.
2. 604128 is the LH Transmission
3. 604127 is the RH Transmission




Élément	Numéro de pièce	Qté	Nom
1	795047	1	PARKING PAWL KIT, EZT
2	798371	1	RING, RETAINING
3	798363	1	GEAR, PARK BRAKE
4	602094	1	FAN / PULLEY KIT
5	607729	1	FAN - 7.0" (10 BLADE)
6	601433	1	KIT, HUB 4 BOLT
Commentaires pour le numéro de pièce 601433 CUSTOMER SERVICE NOTE: Lug Studs are not sold separately.			
7	788877	1	NUT, H-G ZT HUB
8	604903	1	HG RTN SPRING
9	604901	1	HG RTN CW
Not Shown	604902	1	HG RTN CCW



Steering & Brake

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	603983	2	DAMPER
2	781922	4	BALL STUD
3	768523	6	FW 0.343SAE
4	601069	2	CN .312-18x.200 MAX THK
5	768515	4	FW 0.281SAE
6	048553	2	CP .062DX1.000 LG HML Z
7	772483	2	SB0.312X0.750SH0.250-20
8	605273	2	STEERING ROD S/A
9	068551	2	NT .250-20 HXZY NL
10	023655	2	NT 0.312-24 NL G8
11	606575	2	CLIP, SAFETY
12	110370	2	STEERING BAR W/ GRIP
Not Shown	781260	1	GRIP, STEERING BAR
13	029629	5	CS .375-16X0.75 HXF G5ZY
14	767954	4	FW 0.379X.82X.06 HD ZY
15	036244	4	CS .375-16X1.00 HX G5 ZY
16	016899	6	NT .375-16HXG5
17	034272	2	NT .312-18HXG5
18	029751	1	CS .375-16X1.00 HXF G5ZY
19	604173	2	YOKE, 5/16-24
20	041152	6	NT 0.312-24 HX G8
21	605273	2	STEERING ROD S/A
22	116144	2	BLOCK, STEERING CONTROL




Steering Cover Assembly

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	604452	2	CS .250-20X2.00 HX FH ZY
2	768515	4	FW 0.281SAE
3	605529	2	STOP, STEERING
4	551912	1	SERVICE, LATCH
5	029629	1	CS .375-16X0.75 HXF G5ZY
6	016899	1	NT .375-16HXG5
7	055939	2	CS .250-20X0.75 HX G5 ZY
8	601822	2	NUT PLATE, .420 CENTERS
9	781211	2	SWITCH, PUSH BUTTON
10	086660	2	NT .375-16NLG8
11	781708	2	CS .500-13X4.25 HX G5 ZY
12	781567	2	NT .500-13NLG5
13	063198	4	CS #10-24X0.750FLKG5
14	005108	2	CS .375-16X3.500HXG5
15	604288	2	SPACER, STEERING
16	606106	1	STEERING BOX SUB, LH
17	768523	8	FW 0.343SAE
18	058776	4	NT .312-18NLG5
19	604179	2	BRAKE LINK
20	116142	1	BRAKE BLCRNK, LH
21	765339	4	BUSHING,IGUS#0608 (FS)
22	606105	1	STEERING BOX SUB, RH
23	116141	1	BRAKE BLCRNK, RH
24	785220	1	DECAL, STEERING R.S.
25	604195	1	DECAL, ID RAPTOR
26	785139	1	DECAL, STEERING L.S.
27	551698	1	STEERING COVER, SERVICE
28	604275	1	DECAL, DECK HEIGHT
29	781153	2	BUSHING, UHMW

Comments for Page: Steering Cover Assembly

1. The latch and steering cover include decals.
2. 606105 & 606106 are used on mowers S/N 16025348 & higher.
604299 & 604300 are used on mowers S/N prior to 16025348.




Wheel & Tire

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	604013	2	TIR/WHL 18X8.50-8 SLV
2	061077	8	WHEEL NUT
3	705954	2	CS .500-13X1.25 HX G5 ZY
4	344267	2	FW .510X2.15X.19 ZY
5	712976	2	FW 0.531X1.38X.12 ZY
6	784223	4	BEARING
7	784603	2	SPACER
8	N/A	1	FRONT WHEEL ASSEMBLY

Comments for Page: Wheel & Tire


1. Torque to 88–102 N•m.



Front Wheel Assembly Breakdown

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC


Élément	Numéro de pièce	Qté	Nom
1	707398	1	NT .500-13 JAM NY LK
2	767962	2	FW .531 x 1.063 x .175
3	110116	1	CASTER FORK W/A
4	604718	1	CS .500-13X6.00 HX G5 ZY
5	306969	1	GAGE WHEEL SPACER
6	605113	1	TIR/WHL 11X4.00-5 SLV
Not Shown	768044	1	T/W 11X4.00-5 RIBBED
7	772806	2	BEARING CAP
8	772814	1	BEARING, 3/4" ROLLER




Drive Wheel Breakdown

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	604267	1	TIR 18X8.50-8 B2R GRMR
2	601820	1	WHL 8X6.93 4X4.0 SLV
3	019521	1	TIRE VALVE TR-412 GOODY



Élément	Numéro de pièce	Qté	Nom
1		1	ENGINE, KAWASAKI FR651V
2	604463	12"	HOSE, OIL DRAIN
3	604016	1	MUFFLER, FR730V
4	016899	1	NT .375-16HXG5
5	767954	5	FW 0.379X.82X.06 HD ZY
6	121625	1	CLUTCH ANCHOR
7	036244	1	CS .375-16X1.00 HX G5 ZY
8	602580	4	CS .375-16X1.25HXG8ZYP85
9	605574	1	PULLEY, ENG 4.094OP
10	712372	1	KEY 1/4 SQ X 0.66 LG(FS)
11	000331	3	WIRE TIE, SMALL/SHORT
12	791251	1	HARNESS, CLUTCH PIGTAIL
Commentaires pour le numéro de pièce 791251			
Pigtail was updated with epoxy to hold the wires steady. The wire sheath was also updated to a more flexible material.			
13	605595	1	BUSHING, CLUTCH
14	605827K	1	CLUTCH KIT
15	602680	1	FW .453X1.12X.12 HRD ZY
16	785048	1	CS .437-20X3.00 HXG5 P85
17	055939	2	CS .250-20X0.75 HX G5 ZY
18	768515	4	FW 0.281SAE
19	044255	1	NT #10-32HXG5
20	030817	1	STARTER SOLENOID HW KIT
21	024927	2	NT .250-20HXG5
22	029876	1	LW .312 INTEXT ZY
23	720516	1	CS M8-1.25X16HX FL10.9
24	000323	2	CLIP, HOSE CLAMP
25	015818	18"	FUEL LINE, 1/4"
Commentaires pour le numéro de pièce 015818			
Sold by the foot.			
26	604274	1	VAPOR LINE, 3/16 FORMED
27	603524	1	CS M5-0.8 X 50 MM




Comments for Page: Engine, Muffler & Clutch (Multi-Page)

FUEL & VAPOR LINE LENGTH

A : 46cm TANK TO FUEL FILTER (FUEL)

1. Supplied with the engine.
2. Torque to 61–65 N•m. Replace (do not reuse) the cap screw if it is removed or loosened. Use only hand tools to install this fastener.
3. Torque to 41–47 N•m. Replace (do not reuse) the cap screw if it is removed or loosened. Use only hand tools to install this fastener.
4. Torque to 23 N•m.
5. Part of the fuel system.
6. Part of the wire harness.




Engine Service Parts

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	603059	1	AIR FILTER - MAIN
2	068478	1	FUEL FILTER - IN LINE
3	602581	1	ENGINE OIL FILTER
4	604350	1	VALVE, OIL DRAIN
5	604369	1	O-RING

Fuel System


42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC



Fuel System

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC


Élément	Numéro de pièce	Qté	Nom
1	606432	1	FUEL TANK
2	603807	1	CAP, 3.5" RATCHETING GAS
3	117059	1	TANK MNT LEFT
4	117060	1	TANK MNT RIGHT
5	713198	47 cm	SEAL 3/8x3/4 SOLD BY FT
6	055939	3	CS .250-20X0.75 HX G5 ZY
7	768515	3	FW 0.281SAE
8	604279	1	VAPOR LINE, 3/16 FORMED
9	604322	1	1/4" HOSE BARB CROSS
10	604273	1	VAPOR LINE, 3/16 FORMED
11	604292	1	BOOT, 3/16" TO 1/4" BARB
12	604323	1	FILTER, VAPOR SYSTEM
13	000331	2	WIRE TIE, SMALL/SHORT
14	604307	2	MOUNT, PUSH BUTTON
15	033035	56 cm	WEATHERSTRIP .12X.75
16	601400	1	GM .63 x1.13 x.88 x .13



Fuel Tank Service Parts

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	604199K	2	SVC KIT, VENT FITTING
2	604200K	3	SVC KIT, GROMMET
3	605126K	1	SVC KIT, SUCTION HOSE




Service Deck

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	554445	1	42" SERVICE DECK
2	604222	1	DECAL, DANGER / OBJECTS
3	793521	1	DECAL, 42" DECK ID
4	604221	1	DECAL, DANGER / CHUTE

Comments for Page: Service Deck


1. The deck includes the decals.



Deck Pulleys & Spindles

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC


Élément	Numéro de pièce	Qté	Nom
1	781567	2	NT .500-13NLG5
2	767962	2	FW .531 x 1.063 x .175
3	603986	1	IDLER PULLEY, 4.00" FLAT
4	086660	1	NT .375-16NLG8
5	712893	2	FW 0.406X1.25X.12 HD ZY
6	117512	1	IDLER ARM, PIVOTING
7	607616	1	SPRING, DECK IDLER
8	604110	1	ANCHOR, SPRING TENSIONER
9	601839	1	PIVOT SPACER BUSHING
10	117539	1	SPACER, IDLER ARM
11	604253	1	CB .50-13 X 2.00 STD ZN
12	604219	1	IDLER PULLEY, 4.00" FLAT
13	606943	2	NT .562-18 HX NLG5
14	603987	2	PULLEY, 12 POINT
15	604123	2	SPACER, PULLEY
16	036236	8	CS .312-18X1.000HXG5
17	768523	8	FW 0.343SAE
18	604251	1	NT .312-18 HXNL JAM G2ZN
19	122398	1	TENSIONING PULLEY STOP
20	037887	1	CB .312-18X 1.000 FUL YZ
21	080655	1	CS .375-16X1.500HXG5
22	604254	1	CB .50-13 X 2.50 STD ZN
23	604214	2	SPINDLE ASSY, RAP/ALP



Spindle Service Parts - 604214

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	604019	1	BEARING, SPINDLE
2	604218	1	CAST HOUSING
3	607274	1	SVC SHAFT




Deck

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	604403	2	PULLEY COVER
2	604324	4	CS .250-20 X .75 HX FLG
3	602562	2	DECAL, NO SERVICE
4	793828	1	DECK BELT
5	606931	1	DISCHARGE CHUTE
6	606981	1	PIN, CHUTE
7	604331	1	CHUTE SPRING
8	603332	1	CLIP E .66 X .303 X .035
9	606593	2	CS .375-16x2.00 HXG5 P85
10	116157	2	LINK, DECK LIFT
11	016899	2	NT .375-16HXG5
12	116155	2	DECK LINK
13	601839	1	PIVOT SPACER BUSHING
14	605016	1	NUT, DECK LEVELING
15	116911	1	CAM, DECK LEVELER
16	767954	1	FW 0.379X.82X.06 HD ZY
17	706168	1	NT .375-16JAMG5
18	781567	1	NT .500-13NLG5
19	767962	3	FW .531 x 1.063 x .175
20	788166	1	WHEEL ASSY, ANTI SCALP
21	602680	2	FW .453X1.12X.12 HRD ZY
22	754101	2	CS .437-20X1.250HXG5
23	793794	2	BLADE,20.50"-L-F-CW
Not Shown	794685	2	BLADE, F20.50"-H-F-CW
Not Shown	793935	2	BLADE,20.50"-CAT-F-CW
Not Shown	794230	2	BLADE,20.50"GAT-F-CW
24	781708	1	CS .500-13X4.25 HX G5 ZY
25	031997	1	ANTI-SCALP WHEEL
26	053199	1	NT .500-13JAMG5

Comments for Page: Deck

1. Torque to 65 N•m.2. Torque to 2.8–7 N•m.




Deck Lift

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
1	120677	1	HANDLE W/A, DECK LIFT
2	116151	2	PIVOT BLOCK, DECK LIFT
3	029629	4	CS .375-16X0.75 HXF G5ZY
4	016899	6	NT .375-16HXG5
5	604515	4	NT .375-16 FL NY GF
6	604377	1	GRIP, 1/4 X 1.000 BLACK
7	712919	2	FW 0.406X1.00X.12 HD ZY
8	601839	2	PIVOT SPACER BUSHING
9	005116	2	CS .375-16X1.38 HX G5 ZY
10	027714	1	CE0.500X1.250X.156X1.093
11	017251	1	CP .156DX1.000 LG HML Z
12	767962	1	FW .531 x 1.063 x .175
13	029751	2	CS .375-16X1.00 HXF G5ZY
14	121232	1	KIT, DECK PIVOT
Commentaires pour le numéro de pièce 121232			
Kit contains Heavy Duty Deck Lift Rod, Heavy Duty Deck Lift Pivot, and Nut..			

Comments for Page: Deck Lift


1. Part of the Steering Cover Assembly.



Élément	Numéro de pièce	Qté	Nom
1	606146	1	SEAT, SEATS INC 907
2	712927	4	FW 0.344X1.00X.12 HD ZY
3	551897	1	SERVICE, SEAT PAN
4	604307	1	MOUNT, PUSH BUTTON
5	767954	4	FW 0.379X.82X.06 HD ZY
6	086660	2	NT .375-16NLG8
7	000331	1	WIRE TIE, SMALL/SHORT
8	768523	4	FW 0.343SAE
9	036236	4	CS .312-18X1.000HXG5
10	029629	2	CS .375-16X0.75 HXF G5ZY
11	793851	2	SPRING,COMP 1.25X4.00X.
12	016899	2	NT .375-16HXG5
13	036244	2	CS .375-16X1.00 HX G5 ZY
14	601815	1	DECAL, BATTERY WARNINGS
15	602243	1	DECAL, BELT ROUTING
Not Shown	793315	1	SWITCH, SNAP MOUNT

Comments for Page: Seat

1. Do not torque; the seat pan must pivot freely.
2. Torque to 9.5 N•m.
3. The seat pan includes decals.



Seat Service Parts

42" Raptor Parts Manual - 938324CE - HTRTRL042KAWFR651VC

Élément	Numéro de pièce	Qté	Nom
Not Shown	606146	1	SEAT, SEATS INC 907
1	606081	2	SVC, ARM PADS
2	606085	2	SVC, ARMEST SET
3	606082	1	SVC, OPS
4	606147	1	SVC, BACK CUSHION
5	606148	1	SVC, SEAT CUSHION