

OREC

ISSUED NO. RM982F EUO-3

Parts catalogue

Rabbit Mower

(EXPORT MODEL)

RM982F

MODEL	CODE
RM982F/EU	0347-000000

CONTENTS

Fig.1	Frame	1
Fig.3	Transmission	15
Fig.3	HST	23
Fig.4	Handle	25
Fig.5	Front	29
Fig.6	Tire	34
Fig.7	Control	35
Fig.8	Cutting	38
Fig.9	Seat	44
Fig.10	Engine	47
Fig.11	Label	50

OREC CO.,LTD

Update : Dec. 2018

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0322-71200	Wing Stud ϕ 6*14	1	
2	0322-71700	Retainer	1	
3	0347-20600	Step Bumper CMP	1	RH18M00408 ~
	0347-20400	Step Bumper CMP	1	~ RH18D00290
4	89-1211-080252	Mini Hexagonal Bolt M8*25	2	
5	89-1611-080042	Mini Hexagonal Nut M8	2	
6	0347-14700	Front Cover	1	RH18M00408 ~
	0322-70900	Front Cover	1	~ RH18D00290
7	0227-12200	Pointer for Clinometer	1	~ RH18D00290
8	89-1563-080003	Bag Hexagonal U Nut M8(UNI)	1	~ RH18D00290
9	89-1711-080002	Flat Washer 8	1	~ RH18D00290

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0267-40900	Double Spring Bolt M	2	
2	0312-76800	Side Cover (L) Red	1	
3	0312-76700	Side Cover (R) Red	1	
4	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	6	
5	89-1543-080002	Mini Hexagonal Nut (SW) M8	2	
6	89-1714-080002	Flat Washer 8	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0028-70500	Center Step Hinge	4	
2	0301-60400	Rubber 110L	2	
3	0312-70400	Bonnet Clip	1	
4	0347-25100	Step	1	
5	0348-25200	Center Step CMP	1	
6	0341-70100	Step Rubber	1	with foot pedal
	0348-70100	Step Rubber	1	with out foot pedal
7	83-1020-314-00	Washer 8*40*2.3	2	
8	83-1484-369-00	Clip (5347)	18	
9	89-1137-060172	Hexagonal Bolt (PW) M6*17	2	
10	89-1159-080168	Truss Mini Screw M8*16	2	
11	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	6	
12	89-1531-060042	Flange Nut M6	2	
13	89-1543-080002	Mini Hexagonal Nut (SW) M8	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0347-20300	Sub Frame CMP	1	
2	89-1213-100652	Mini Hexagpnal Bolt (8T) M10*65	2	
3	89-1631-100042	Flange Mini Hexagonal Nut M10	2	
4	89-1714-100002	Flat Washer 10	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0322-71000	Fuel Tank Assy	1	Include : 4,5,6,7,11
1	80-1920-306-00	Stopper Rubber B-4	1	
2	0322-60200	Rear Fender Cover (R)	1	
3	0322-60400	Fuel Tank Cover Stay	1	
4	0322-70100	Fuel Tank CMP	1	
5	0322-76000	Fuel Tank Cap Assy (with valve)	1	
6	0322-70600	Fuel Gauge	1	
7	0322-70700	Fuel Filter	1	
8	0322-73200	Tank Cover White	1	
9	0348-20300	Fuel Tank Holder CMP	1	
10	89-1111-060252	Hexagonal Bolt M6*25	1	
11	89-1152-050122	Cross recess Headed Screw M5*12	2	
12	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	2	
13	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	6	
14	89-1238-080162	Mini Hexagonal Bolt (SW) M8*16	2	
15	89-1531-060042	Flange Nut M6	1	
16	89-1711-060002	Flat Washer 6	1	
17	89-1713-080002	Flat Washer 8 (large)	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0207-75400	Brake Spring 30	1	
2	0301-60400	Rubber 110L	1	Kawasaki
	80-1482-492-00	Rubber L40	1	Briggs & Stratton
3	0322-73800	Rubber	1	Briggs & Stratton
4	0347-42100	Rear Belt Cover (K)	1	Kawasaki
	0347-42400	Rear Belt Cover (B&S)	1	Briggs & Stratton
5	Transmission Part	-	1	Page 15 ~
6	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	
7	89-1561-080002	Mini Hexagonal U Nut M8	1	
8	89-1611-080042	Mini Hexagonal Nut M8	1	
9	89-1631-080042	Flange Mini Hexagonal Nut M8	1	
10	89-1711-080002	Flat Washer 8	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0207-77100	Battery Plus Cord 230	1	
2	0227-32200	Center Pin CMP (RM980F)	1	
3	0322-72200	Battery Minus Cord	1	
4	0322-72300	Cushion Rubber (Battery)	1	
5	Front Part	-	1	Page 29 ~
6	Handle Part	-	1	Page 25 ~
7	0348-20700	Battery Setting Stay	1	RH18M00408 ~
8	0348-20800	Battery Setting Bolt	2	RH18M00408 ~
9	83-1415-975-00	Grease Nipple M6	1	
10	83-1481-328-00	Washer 12*30*3.2	1	
11	89-1236-080252	Mini Hexagonal Bolt (PWSW) M8*25	4	
12	89-1551-060002	Hexagonal U Nut M6	2	RH18M00408 ~
13	89-1551-120002	Hexagonal U Nut M12	1	
14	89-1711-060002	Flat Washer 6	2	RH18M00408 ~
15	89-1750-120002	Spring Washer 12	1	
16	89-3510-025350	DU Bush 25.35	2	
17	0322-22200	Battery Holder	1	~ RH18D00290
18	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	~ RH18D00290
19	89-1631-080042	Flange Mini Hexagonal Nut M8	3	~ RH18D00290
20	0347-73100	Wire Harness Long (RM982F/K)	1	RH18M00408 ~
	0347-72100	Wire Harness (RM982F/K)	1	~ RH18D00290

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1493-354-00	Rod Return Spring	1	
2-2	0310-73700	Pedal Rubber	1	RH17M00070 ~
2-1	0312-71100	Brake Pedal Rubber		~ RH17E00069
3	0312-23100	Brake Stopper CMP	1	
4	0312-23200	Brake Stopper Return Spring	1	
5	0329-60210	Center Belt Cover (RMK150)	1	
6	0347-10100	Pedal Stay CMP	1	
7	0347-10200	Change Pedal CMP	1	
8-2	0347-10400	Brake Pedal CMP	1	RH17M00070 ~
8-1	0347-10400	Brake Pedal CMP	1	~ RH17E00069
9	0347-12100	Brake Rod CMP	1	
10	Control Part	-	1	Page 35 ~
11	83-1415-975-00	Grease Nipple M6	1	
12	83-1515-975-00	Grease Nipple C-Type M6	1	
13	89-1213-100302	Mini Hexagonal Bolt (8T) M10*30	1	
14	89-1113-100357	Hexagonal Bolt (8T) M10*35	1	
15	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	
16	89-1611-100042	Mini Hexagonal Nut M10	1	
17	89-1631-100042	Flange Mini Hexagonal Nut M10	1	
18	89-1711-120002	Flat Washer 12	1	
19	89-2131-120002	Snap Pin 12	1	
20	89-2521-000120	E Type Ring 12	3	
21	89-3510-016150	DU Bush 16.15	1	
22	89-3510-016250	DU Bush 16.25	4	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0227-41000	Knife Tension Pulley (A) Set	2	Include : 4,5,11,13,14
1	80-1482-549-00	Rubber Cover 58	2	
2	80-1483-568-00	Knife Tension Return Spring	1	
3	0207-78400	Spring For Knife Tension Return	1	
4	0227-40300	Knife Tension Pulley (A)	2	
5	0244-42800	Tension Idler Shaft	2	
6	0329-41200	Knife Tension Arm CMP(RMK150)	1	
7	83-1020-363-00	Thrust Washer 16*24*1.0	2	
8	89-1613-100042	Mini Hexagonal Nut (3 sorts) M10	2	
9	89-1713-100002	Flat Washer 10 (large)	2	
10	89-1750-100002	Spring Washer 10	2	
11	89-2511-000150	Snap Ring (S15)	2	
12	89-2511-000160	Snap Ring (S16)	1	
13	89-2512-000350	Snap Ring (R35)	2	
14	89-3115-062024	Bearing 6202 2RS	4	
15	89-3510-016250	DU Bush 16.25	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	83-1032-760-00	Tension Pulley Assy	1	Include : 7,13,14
1	80-1482-549-00	Rubber Cover 58	1	
2	80-1485-551-00	Driving Tension Spring	1	
3	0312-41400	Belt Holder CMP (Engine)	1	RH17M00070 ~
	0347-41200	Belt Holder CMP (Engine)	1	~ RH17E00069
4	0322-41400	Driving Tension Spring Arm	1	
5	0347-41100	Driving Tension Arm CMP	1	
6	83-1020-363-00	Thrust Washer 16*24*1.0	2	
7	83-1032-765-00	Tension Pulley	1	
8	89-1211-100252	Mini Hexagonal Bolt M10*25	1	
9	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	1	
10	89-1611-100042	Mini Hexagonal Nut M10	1	
11	89-2511-000160	Snap Ring (S16)	1	
12	89-2511-000170	Snap Ring (S17)	1	
13	89-2512-000400	Snap Ring (R40)	1	
14	89-3115-062034	Bearing 6203 2RS	1	
15	89-3510-016150	DU Bush 16.15	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0347-53000	Link Pin Assy (with Nipple)	1	Include : 6,9
1	80-1484-276-10	Spring (Up/Down)	2	
2	0207-76800	Washer 16*32*2.3	2	
3	0347-52100	Front Link Arm (R) CMP	1	
4	0347-52200	Front Link Arm (L) CMP	1	
5	0347-52300	Connecting Plate	2	
6	0347-53100	Link Pin	1	
7	0348-50500	Rear Link Arm (R) CMP	1	
8	0348-50600	Rear Link Arm (L) CMP	1	
9	83-1415-975-00	Grease Nipple M6	8	
10	83-1751-311-00	Flat Washer 8*25*2.3	2	
11	89-1232-080162	Mini Hexagonal Bolt (SW) M8*16	2	
12	89-2131-160002	Snap Pin 16	2	
13	89-2521-000120	E Type Ring 12	9	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0322-73700	Gas Spring Free Lock Type(FLC75- 60) set	1	Include : 2,8
-	0244-11000	Adjusting Rod Assy	1	Include : 4,5,6,11
1	80-1484-354-10	Brake Rod Roller	1	
2	0244-10500	Lock Pusher	1	
3	0244-11300	Push Rod Receiver CMP	1	
4	0244-11400	Adjuster Rod (R)	1	
5	0244-11500	Adjuster Rod (L)	1	
6	0244-11600	Turn Buckle (Pipe Type)	1	
7	0244-22600	Brake Rod Hung Plate	1	
8	0322-73900	Gas Spring Free Lock Type(FLC75- 60)	1	
9	83-1020-355-00	Thrust Washer 12*24*1.0	2	
10	89-1137-060122	Hexagonal Bolt (PW) M6*12	1	
11	89-1511-060042	Hexagonal Nut M6	1	
12	89-1543-080002	Mini Hexagonal Nut (SW) M8	1	
13	89-1711-060002	Flat Washer 6	3	
14	89-1711-080002	Flat Washer 8	2	
15	89-2131-080002	Snap Pin 8	2	
16	89-2132-060002	Snap Pin 6 (with stopper)	3	
17	89-2181-060202	Flat Head Pin 6*20	1	
18	89-2181-080282	Flat Head Pin 8*28	1	
19	89-2181-080692	Flat Head Pin 8*69	1	
20	89-3510-012200	DU Bush 12.20	1	
21	89-3511-010150	DU Bush 10.15.18F	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1792-988-00	Harness Clip 8	2	
2	0207-72800	Switch Lock Nut	2	
3	0207-74400	Safety Switch K17850	2	
4	0227-00900	Wire Band	1	
5	0244-11200	Push Rod	1	
6	0244-13700	Wire Joint CMP	1	
7	0244-70200	Adjusting Shaft Grip	1	
8	0289-71300	Arm Grip (Red)	1	
9	0322-75210	Knife Brake Wire	1	
10	0322-75110	Knife Clutch Wire	1	
11	0322-13300	Safety Switch Setting Plate	1	
12	0347-20100	Frame CMP	1	
13	0348-12100	Knife Clutch Lever CMP	1	
14	0348-50400	Up/Down Adjusting Shaft CMP	1	
15	89-1132-060162	Hexagonal Bolt (SW) M6*16	2	
16	89-1138-060162	Hexagonal Bolt (SW) M6*16	1	
17	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	4	
18	89-1531-060042	Flange Nut M6	1	
19	89-1631-080042	Flange Mini Hexagonal Nut M8	1	
20	89-1711-060002	Flat Washer 6	3	
21	89-2132-060002	Snap Pin 6 (with stopper)	3	
22	89-2521-000120	E Type Ring 12	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1792-988-00	Harness Clip 8	1	
2	0229-13100	Rubber, L20	1	
3	0322-22500	Upper Belt Cover	1	
4	Seat Part	-	1	Page 44 ~
5	Engine Part	-	1	Page 47 ~
6	Cutting Part	-	1	Page 38 ~
7	0227-74200	Wire Band 300	1	
8	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	

15/51 Transmission 1/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1425-551-00	Differential Lock Spring	1	
2	0207-77800	Wheel Boss Dust Seal	2	
3	0227-02200	Fan Cover Setting CMP (RM980F)	1	
4	0207-07200	Fan Cover CMP	1	RH18M00408 ~
	0227-02900	Fan Cover CMP (RM980F)	1	~ RH18D00290
5	0244-74300	Rear Tire (R) Assy (17×8.00-8)(Include Wheel Boss)	1	
6	0244-74400	Rear Tire (L) Assy (17×8.00-8)(Include Wheel Boss)	1	
7	0244-83200	Mini Hexagonal Bolt (PWSW) M10*25 (7T Lock)	4	
8	0347-01100	Transmission Hanger Stay CMP	1	
9	83-1630-335-00	Washer 16*40*4.5	2	
10	89-1211-080352	Mini Hexagonal Bolt M8*35	1	
11	89-1561-080002	Mini Hexagonal U Nut M8	1	
12	89-1631-080042	Flange Mini Hexagonal Nut M8	3	
13	89-1658-160042	Low Fluted Nut (2 sorts) M16	2	
14	89-1750-080002	Spring Washer 8	1	
15	89-1750-160002	Spring Washer 16	2	
16	89-2120-350352	Split Pin 3.5*35	2	
17	89-2150-070500	Key 7*50 (round)	2	

16/51 Transmission 2/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0207-03100	Mission Guard CMP	1	
2	0227-00300	Fan (RM980F)	1	
3	0227-02300	Double Spring Bolt 125	2	
4	HST Part	-	1	Page 23 ~
5	89-1232-080122	Mini Hexagonal Bolt (SW) M8*12	4	
6	89-1251-081303	Flange Mini Hexagonal Bolt M8*130	2	
7	89-1750-080002	Spring Washer 8	2	
8	89-2150-050200	Key 5*20 (round)	1	
9	89-5222-045000	O Ring G45	2	

17/51 Transmission 3/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0207-73000	Brake Assy(with packing)	1	Include : 1,2,4,5,6,7,9,11,13
-	0207-73100	Brake Assy(without packing)	1	Include : 1,2,4,5,6,9,11,13
-	0207-73200	Brake Cap Assy	1	Include : 2,4,5,6,9,11,13
1	80-1030-282-00	Brake Drum (PA-7)	1	
2	80-1030-285-00	Spring for Brake Shoe Return	1	
3	0207-10300	Brake Joint	1	
4	-	-	1	
5	-	-	1	
6	0244-88100	Brake Shoe Set (PA-7)	1	
7	0308-00300	Brake Cover PK (PA-7)	1	
8	89-1113-060122	Hexagonal Bolt (8T) M6*12	4	
9	89-1611-100042	Mini Hexagonal Nut M10	1	
10	89-1711-080002	Flat Washer 8	1	
11	89-1712-100000	Flat Washer 10	1	
12	89-1750-060002	Spring Washer 6	4	
13	89-1750-100002	Spring Washer 10	1	
14	89-2120-200152	Split Pin 2*15	1	
15	89-2511-000150	Snap Ring (S15)	1	
16	89-5125-153007	Oil Seal UE 15.30.07F	1	

18/51 Transmission 4/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0289-01000	Oil Plug Assy (with O Ring)	1	Include : 2,15
-	0244-08000	Oil Seal 25.47.15(with DP)	1	Include : 5,14
1	0215-00100	Driving Clutch Arm	1	
2	0289-01100	Oil Plug Assy (without O Ring)	1	
3	0312-01100	Axle Case (L) CMP	1	
4	83-1020-349-00	Copper Packing 10.5*18*1.6	1	
5	83-1415-663-00	Oil Seal DP 25.30.15	1	
6	83-1415-671-00	Blind Cover 22	1	
7	89-1238-080202	Mini Hexagonal Bolt (SW) M8*20	6	
8	89-1252-100122	Flange Mini Hexagonal Bolt M10*12 (slender)	1	
9	89-1543-080002	Mini Hexagonal Nut (SW) M8	1	
10	89-2512-000470	Snap Ring (R47)	1	
11	89-3115-060054	Bearing 6005 2RS	2	
12	89-5121-122207	Oil Seal UE 12.22.7	1	
13	89-5121-284708	Oil Seal UE 28.47.8	1	
14	89-5121-304707	Oil Seal UE 30.47.7	1	
15	89-5221-024000	O Ring P24	1	

19/51 Transmission 5/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1310-138-00	Spring 1.4	1	
2	0207-00100	Transmission Case(L)	1	
3	0207-00400	20T Spiral Mita Gear(L)	1	
4	0207-01700	Swing Arm CMP	1	
5	0207-01900	Shift Spring Holder	1	
6	0207-40200	Transmission Pulley	1	
7	0281-00300	A Axle	1	
8	83-1020-148-00	Tapping Bolt M6*14	2	
9	83-1482-143-00	Tapping Bolt M8*25	12	
10	83-1482-311-00	Washer 6.5*22*3.2	1	
11	89-1113-060202	Hexagonal Bolt (8T) M6*20	1	
12	89-1750-060002	Spring Washer 6	1	
13	89-2150-050160	Key 5*16 (round)	1	
14	89-2151-050200	Key 5*20 (half round)	1	
15	89-2511-000170	Snap Ring (S17)	1	
16	89-2512-000420	Snap Ring (R42)	1	
17	89-3115-060044	Bearing 6004 2RS	2	
18	89-3410-080000	Steel Ball 8.0	1	
19	89-5121-204208	Oil Seal UE 20.42.8	1	

20/51 Transmission 6/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0207-00500	20T Spiral Mita Gear(R)	1	
2	0207-00700	C Axle	1	
3	0207-01310	Brake Shaft 34T Gear	1	
4	0207-01400	D Axle 37T Gear	1	
5	0207-01600	Shift Fork Shaft CMP	1	
6	0207-02700	D Axle	1	
7	0215-00300	Brake Shaft	1	
8	0215-00400	Shift Gear 28	1	
9	0215-00500	C Axle Collar 26	1	
10	0227-00100	B Axle	1	
11	83-1020-361-00	Thrust Washer 15*24*1.0	1	
12	89-3111-060044	Bearing 6004	4	
13	89-3111-062024	Bearing 6202	2	
14	89-3111-062034	Bearing 6203	2	

21/51 Transmission 7/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0244-08000	Oil Seal 25.47.15(with DP)	1	Include : 7,17
1	80-1488-153-00	Differential Lock Arm	1	
2	80-1830-113-00	Differential Lock Fork	1	
3	0207-00200	Transmission Case(R)	1	
4	0207-01800	Differential Lock Fork Shaft	1	
5	0207-06100	Air Bleezer	1	
6	0312-01200	Axle Case (R) CMP	1	
7	83-1415-663-00	Oil Seal DP 25.30.15	1	
8	83-1415-671-00	Blind Cover 22	1	
9	89-1232-080202	Mini Hexagonal Bolt (SW) M8*20	6	
10	89-1543-080002	Mini Hexagonal Nut (SW) M8	1	
11	89-2111-030020	Spring Pin 3*20	1	
12	89-2111-050022	Spring Pin 5*22	1	
13	89-2512-000470	Snap Ring (R47)	1	
14	89-3115-060054	Bearing 6005 2RS	2	
15	89-5121-122207	Oil Seal UE 12.22.7	1	
16	89-5121-284708	Oil Seal UE 28.47.8	1	
17	89-5121-304707	Oil Seal UE 30.47.7	1	

22/51 Transmission 8/8

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1415-150-00	Axle Pin	1	
2	80-1425-143-00	Differential Lock Cone	1	
3	80-1481-151-00	Differential Lock Plate	1	
4	80-1481-152-00	Differential Lock Gear 11T	4	
5	80-1481-155-00	Differential Gear Shaft Collar	4	
6	80-1751-162-00	Differential Lock Spring	1	
7	0207-02800	Axle Gear CMP	1	
8	0312-02100	Axle (L) CMP	1	
9	0312-02200	Axle (R) CMP	1	
10	83-1830-382-00	Thrust Washer 40*48*1.0	1	
11	89-1613-100042	Mini Hexagonal Nut (3 sorts) M10	6	
12	89-1750-100002	Spring Washer 10	6	
13	89-2511-000280	Snap Ring (S28)	1	
14	89-2511-000400	Snap Ring (S40)	1	
15	89-3410-075000	Steel Ball 7.5	3	
16	89-3510-028300	DU Bush 28.30	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0227-01400	Port Joint 7/8-14UNF	1	
2	0227-01500	Poet Joint G1/4	1	
3	0227-02600	HST Hose	1	
4	0227-02700	HST Hose (Oil Filter)	2	
5	0227-03100	Hose Clip 17	2	
6	0312-74400	Hose Band 16-25	5	
7	0347-00500	HST Oil Tank Setting CMP	1	
8	0347-01200	HST Oil Tank CMP	1	
9	0347-01300	HST Oil Tank Cap (KRM-ABG2-FW)	1	
10	0347-01400	Oil Gauge Window (KMH-4)	1	
11	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	
12	0227-00600	HST Hose	1	
13	0347-00200	Oil Filter	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0227-00400	Oil Pressure Hose 1590	1	
2	0227-00700	Different Diameter Joint	2	
3	0227-01300	Oil Pressure Hose 1670	1	
4	0347-02100	Control Arm CMP	1	
5	89-1113-060202	Hexagonal Bolt (8T) M6*20	1	
6	89-1511-060042	Hexagonal Nut M6	1	
7	0227-01110	HST Unit 13cc(New)	1	RH18M00408 ~

25/51 Handle 1/4

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0262-70100	Steering Wheel Assy	1	Include : 2,3,4
1	0207-79200	Fuse Box Bracket	1	
2	0262-70300	Sub Handle Assy	1	
3	0262-70400	Steering Wheel	1	
4	0262-70500	Steering Cap	1	
5	0312-11700	Handle Stay Cover Holder	2	
6	0312-70200	Head Lamp	2	RH18M00408 ~
	0322-71300	Head Lamp	1	~ RH18D00290
7	0312-77900	Fuse Box Cover	1	only cover
8	0322-11500	Meter Panel Cover	1	
9	0322-71100	Clip φ 6	1	
10	0322-71200	Wing Stud φ 6*14	1	
11	0322-71700	Retainer	1	
12	0322-73000	Magnet Switch Set	1	
13	0347-14500	Front Cover Stay	1	RH18M00408 ~
14	0348-14700	Fuse Box Bracket	1	
15	89-1137-060152	Hexagonal Bolt (PW) M6*15	4	
16	89-1159-060108	Truss Mini Screw M6*10	4	
17	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	4	
18	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	RH18M00408 ~
19	89-1390-060162	Welded Bolt M6*16	1	
20	89-1531-060042	Flange Nut M6	4	
21	89-1541-060002	Hexagonal Nut (SW) M6	1	
22	89-1561-100002	Mini Hexagonal U Nut M10	1	
23	89-1713-100002	Flat Washer 10 (large)	1	
24	89-1812-060002	Toothed washer (inside) 6	1	
25	89-1631-080042	Flange Mini Hexagonal Nut M8	1	~ RH18D00290

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1482-493-00	Ditch Gum L73	1	RH18M00408 ~
2	0207-79300	Pilot Lamp	1	
3	0207-79700	Key Switch (NMA03-A020)	1	
4	0227-12200	Pointer for Clinometer	1	
5	0229-13100	Rubber, L20	2	RH18M00408 ~
6	0244-70300	Lighting Switch	1	
7	0244-70400	Lamp, Caution for Engine Oil	1	
8	0244-73600	Hour Meter	1	
9	0322-11100	Tilt Pin CMP	1	
10	0347-13800	Steering Gear Box Holder	1	
11	0347-13900	Steering Gear Box Cover	1	RH18M00408 ~
12	0347-14100	Handle Stay CMP	1	RH18M00408 ~
	0347-13400	Handle Stay CMP	1	~ RH18D00290
13	0347-14400	Head Lamp Stay CMP	1	RH18M00408 ~
	0347-13700	Head Lamp Stay	1	~ RH18D00290
14	0347-14800	Meter Panel Stay CMP	1	RH18M00408 ~
15	0347-15400	Meter Panel CMP	1	RH18M00408 ~
	0347-13500	Meter Panel CMP	1	~ RH18D00290
16	0348-10700	Flat Washer 9*35*3.2	1	
17	0348-70200	Choke Wire	1	
18	0348-71400	Cramp Lever	1	
19	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	4	
20	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	11	
21	89-1563-080003	Bag Hexagonal U Nut M8(UNI)	1	
22	89-1631-080042	Flange Mini Hexagonal Nut M8	2	
23	89-1711-080002	Flat Washer 8	1	
24	89-1750-080002	Spring Washer 8	1	

27/51 Handle 3/4

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0245-71000	Universal Joint Assy	1	Include : 7,8,9
-	0227-33000	Tie Rod Adjuster Assy	1	Include : 2,3,4,5,6,19
1	0212-72100	Hexagonal Bolt(8T) M10*25(Meck)	1	
2	0227-32100	Tie Rod Adjuster	1	
3	0244-71700	Link Ball 12 (R)	1	
4	0244-71800	Link Ball 12 (L)	1	
5	0244-71900	Tough Lock Nut M12=P1.25	2	
6	0244-73800	Hexagonal Nut (slender) M12 Left	1	
7	0245-71100	Universal Joint NC-12	1	
8	0245-71200	Universal Joint Pin	2	
9	0245-71300	Universal Joint Ring	2	
10	0347-13000	Steering Gear Box Assy	1	
11	0347-13100	Steering Arm CMP	1	
12	0347-14200	Steering Lower Shaft(Long)	1	RH18M00408 ~
	0347-13200	Steering Lower Shaft	1	~ RH18D00290
13	0347-14300	Steering Upper Shaft CMP(Long)	1	RH18M00408 ~
	0347-13310	Steering Upper Shaft CMP	1	~ RH18D00290
14	0348-14310	Handle Support CMP	1	
15	0348-14600	Bolt for Upper Shaft Setting	1	
16	83-1610-324-00	Washer 10*36*3.2	1	
17	89-1236-080252	Mini Hexagonal Bolt (PWSW) M8*25	4	
18	89-1553-060002	Bag Hexagonal U Nut M6	1	
19	89-1612-120042	Mini Hexagonal Nut (Slender) M12	1	
20	89-1750-100002	Spring Washer 10	1	
21	89-2151-070240	Key 7*24 (half round)	1	
22	89-3511-025250	DU Bush 25.25.36F	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0347-13000	Steering Gear Box Assy	1	Include : 1~23
1	80-1321-131-10	2nd Shaft 13T	1	
2	0223-01500	3rd Shaft Gear 31T	1	
3	0227-36100	Steering Gear Box (A)	1	
4	0227-36200	Steering Gear Box (B)	1	
5	0227-36300	Bevel Gear 34T	1	
6	0227-36400	2nd Shaft	1	
7	0227-36500	2nd Shaft 12T	1	
8	0227-36600	1st Shaft	1	
9	0227-36700	Steering Output Shaft	1	
10	0313-05400	Bevel Gear 19T	1	
11	0347-13600	Handle Input Shaft	1	
12	83-1017-365-10	Thrust Washer 17*23*1.0	2	
13	83-1020-361-00	Thrust Washer 15*24*1.0	1	
14	83-1515-148-00	Tapping Bolt M6*22	8	
15	89-2511-000100	Snap Ring (S10)	1	
16	89-2512-000400	Snap Ring (R40)	1	
17	89-3111-060024	Bearing 6002	1	
18	89-3111-060034	Bearing 6003	1	
19	89-3111-062024	Bearing 6202	3	
20	89-3115-062034	Bearing 6203 2RS	2	
21	89-3115-062054	Bearing 6205 2RS	1	
22	89-5121-204008	Oil Seal UE 20.40.8	1	
23	89-5121-253808	Oil Seal UE 25.38.8	1	

29/51 Front 1/5

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0227-31100	Front Flapper Stay (Left) CMP	1	
2	0227-31200	Front Flapper Stay (Right) CMP	1	
3	0227-60100	Front Flapper	1	
4	0227-60310	Upper Flapper	1	
5	0227-60400	Front Upper Guard CMP	1	
6	0244-61700	Upper Flapper Holder	1	
7	0284-53200	Upper Flapper	1	
8	0347-31200	Front Flapper Holder	1	
9	0347-31300	Foot Guard CMP	1	
10	89-1137-060152	Hexagonal Bolt (PW) M6*15	8	
11	89-1232-100202	Mini Hexagonal Bolt (SW) M10*20	2	
12	89-1253-080302	Flange Mini Hexagonal Bolt (8T) M8*30	4	
13	89-1581-060042	Flange Cap Nut M6	2	
14	89-1631-100042	Flange Mini Hexagonal Nut M10	2	
15	89-1713-060002	Flat Washer 6 (large)	2	
16	89-1713-100002	Flat Washer 10 (large)	4	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0227-70510	Front Wheel Tire (L) ASSY (Include Wheel Boss)	1	Include : 2,7,8,9
-	0227-70410	Front Wheel Tire (R) ASSY (Include Wheel Boss)	1	Include : 2,6,8,9
1	0010-71500	Thrust Washer 19*25*1.0	2	
2	0227-30110	Front Wheel Boss	2	
3	0227-32300	Key 3/16*3/16*50	2	
4	0227-32400	Snap Ring for Axes(RM980F)	2	
5	0227-70300	Front Wheel Cap (φ42L*50)	2	
6	0244-79110	Front Wheel Tire (R) Assy (400-7)	1	
7	0244-79210	Front Wheel Tire (L) Assy (4.00-7)	1	
8	89-1113-100252	Hexagonal Bolt (8T) M10*25	8	
9	89-1750-100002	Spring Washer 10	8	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0227-30210	Front Wheel Rubber Cover Installation	1	
2	0227-30400	Front Wheel Rubber Cover	1	
3	0227-30700	Front Axle Cover Left CMP	1	
4	0227-30800	Axle Cover Flapper	1	
5	0227-30900	Steering Knuckle Arm	1	
6	0227-32600	Axle Dust Guard	1	
7	0227-32700	Front Wheel Rubber Cover Press	1	
8	89-1111-120952	Hexagonal Bolt M12*95	1	
9	89-1113-120352	Hexagonal Bolt (8T) M12*35	1	
10	89-1137-060152	Hexagonal Bolt (PW) M6*15	2	
11	89-1631-080042	Flange Mini Hexagonal Nut M8	4	
12	89-1713-060002	Flat Washer 6 (large)	2	
13	89-1713-120002	Flat Washer 12 (large)	2	
14	89-1750-120002	Spring Washer 12	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0227-30210	Front Wheel Rubber Cover Installation	1	
2	0227-30400	Front Wheel Rubber Cover	1	
3	0227-30600	Front Axle Cover Right CMP	1	
4	0227-30800	Axle Cover Flapper	1	
5	0227-32600	Axle Dust Guard	1	
6	0227-32700	Front Wheel Rubber Cover Press	1	
7	89-1111-120252	Hexagonal Bolt M12*25	2	
8	89-1137-060152	Hexagonal Bolt (PW) M6*15	2	
9	89-1631-080042	Flange Mini Hexagonal Nut M8	4	
10	89-1713-060002	Flat Washer 6 (large)	2	
11	89-1713-120002	Flat Washer 12 (large)	2	
12	89-1750-120002	Spring Washer 12	2	

33/51 Front 5/5

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0227-00400	Oil Pressure Hose 1590	1	
2	0227-00500	Hose Joint	1	
3	0227-00600	HST Hose	1	
4	0227-00800	Joint 3-4-16UNF	1	
5	0227-01300	Oil Pressure Hose 1670	1	
6	0227-01600	Adjustable Elbow	1	
7	0227-01700	Hose Press Board	1	
8	0312-74400	Hose Band 16-25	1	
9	0347-31100	Front Axle Holder CMP	1	
10	0244-83200	Mini Hexagonal Bolt (PWSW) M10*25 (7T Lock)	6	RH18M00408 ~
	89-1232-100252	Mini Hexagonal Bolt (SW) M10*25	6	~ RH18D00290
11	89-1238-080202	Mini Hexagonal Bolt (SW) M8*20	1	
12	89-1239-080162	Mini Hexagonal Bolt (PWSW) M8*16	1	
13	89-5221-014000	O Ring P14	1	
14	0227-01210	Front Unit Assy (KXH-10F)	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1260-404-00	Tire Tube 3.50-7	2	
2	80-1260-407-00	Wheel Assy 3.50-7	2	
3	0244-78610	Tire 17*8.00-8	2	
4	0244-78300	Tire Tube 17*8.00-8	2	
5	0244-78800	Wheel Assy 17*800-8	4	
6	0207-31200	Rear Wheel Boss	2	
7	0244-79310	Tire (4.00-7)	2	
8	89-1113-100252	Hexagonal Bolt (8T) M10*25	8	
9	89-1213-080162	Mini Hexagonal Bolt (8T) M8*16	8	
10	89-1213-080162	Mini Hexagonal Bolt (8T) M8*16	12	
11	89-1543-080002	Mini Hexagonal Nut (SW) M8	20	
12	89-1750-100002	Spring Washer 10	8	

35/51 Control 1/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0348-11000	Shift Rod Assy	1	Include : 1,2,3,9,10,13
-	0342-15010	Change Pedal Rod Assy	1	Include : 1,2,3,8,10,13
1	80-1485-265-00	Shift Rod Adjuster	2	
2	80-1487-962-10	Rod End PHS10ECL	2	
3	80-1487-964-10	Rod End PHS10EC	2	
4	0207-72600	Lever Grip 8 (black)	1	
5	0215-70600	Lever Grip (Red)	1	
6	0221-13200	Change Grip	1	
7	0341-10200	Control Guide CMP	1	
8	0342-15110	Change Pedal Rod	1	
9	0348-11100	Shift Rod	1	
10	83-1488-195-02	Mini Hexagonal Nut M10 (L)	2	
11	89-1213-100302	Mini Hexagonal Bolt (8T) M10*30	2	
12	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	4	
13	89-1611-100042	Mini Hexagonal Nut M10	4	
14	89-1613-100042	Mini Hexagonal Nut (3 sorts) M10	1	
15	89-1631-100042	Flange Mini Hexagonal Nut M10	3	
16	89-1711-100002	Flat Washer 10*18*1.6	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0312-17010	Change Brake Assy	1	Include : 5,6,9,10
1	0207-72300	Change Brake Adjuster	1	~ RH17E00069
2	0225-11800	Spring, Change Brake	1	~ RH17E00069
3	0312-12900	Throttle Lever	1	
4	0312-14200	Spring for Brake Pulling	1	~ RH17E00069
5	0312-17100	Brake Cover	1	~ RH17E00069
6	0312-17200	Brake Drum	1	~ RH17E00069
7	0312-75100	Throttle Wire	1	
8	83-1675-375-00	Thrust Washer 14*23*1.0	1	~ RH17E00069
9	85-1711-317-00	Shoe Return Spring	2	~ RH17E00069
10	85-1711-318-00	Brake Shoe Set	1	~ RH17E00069
11	89-1113-060122	Hexagonal Bolt (8T) M6*12	3	~ RH17E00069
12	89-1561-100002	Mini Hexagonal U Nut M10	1	
13	89-1611-080042	Mini Hexagonal Nut M8	2	~ RH17E00069
14	89-1611-100042	Mini Hexagonal Nut M10	1	
15	89-1750-060002	Spring Washer 6	3	~ RH17E00069
16	89-1852-100001	Belleville Spring H10	2	
17	89-2132-060002	Snap Pin 6 (with stopper)	1	~ RH17E00069
18	89-2150-050100	Key 5*10 (round)	1	~ RH17E00069
19	89-2181-060122	Flat Head Pin 6*12	1	~ RH17E00069
20	89-2511-000140	Snap Ring (S14)	1	~ RH17E00069

37/51 Control 3/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1020-263-00	Control Lever Shaft Spring	1	
2	0244-13200	Differential Lock Lever CMP	1	
3	0244-72410	Defferential Lock Wire	1	
4	0312-12100	Change Bracket CMP	1	
5	0312-12310	Neutral Arm	2	
6	0347-16200	Change Lever Base CMP	1	RH18M00408 ~
	0312-12420	Change Lever Base CMP	1	~ RH18D00290
7	0312-13700	Spring for Change Lever	1	~ RH18D00290
8	0312-13800	Spring for Change Return Arm	1	
9	0322-12400	Change Return Arm CMP	1	
10	0329-12500	Spring for Change Pedal	1	
11	0347-16100	Change Lever Guide CMP	1	RH18M00408 ~
	0348-15100	Change Lever Guide CMP	1	RH17M00070 ~
	0348-10100	Change Lever Guide CMP	1	~ RH17M00069
12	0348-10300	Change Lever CMP	1	
13	89-1113-060452	Hexagonal Bolt (8T) M6*45	1	RH17M00070 ~
	89-1113-060552	Hexagonal Bolt (8T) M6*55	1	~ RH17M00069
14	89-1551-060002	Hexagonal U Nut M6	1	
15	89-1561-100002	Mini Hexagonal U Nut M10	1	
16	89-1711-100002	Flat Washer 10*18*1.6	1	
17	89-1713-060002	Flat Washer 6 (large)	1	~ RH18D00290
18	89-2132-060002	Snap Pin 6 (with stopper)	1	
19	89-2181-060162	Flat Head Pin 6*16	1	
20	89-2521-000100	E Type Ring 10	1	
21	89-2521-000120	E Type Ring 12	2	
22	89-3510-016150	DU Bush 16.15	6	
23	83-1020-363-00	Thrust Washer 16*24*1.0	1	RH18M00408 ~

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1792-988-00	Harness Clip 8	1	
2	0244-42400	Knife Pulley Belt Holder (L)	1	
3	0244-42600	Knife Pulley Belt Holder	1	
4	0347-50200	Knife Belt Cover CMP	1	
5	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	3	
6	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	3	
7	89-6123-008002	V Belt SB-80 (W800)	1	

39/51 Cutting 2/6

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1488-747-00	Bolt for Right Cover Up/Down Arm	1	
2	0244-63900	Round Head Pin 10*72	2	
3	0244-71600	Spring for Right Cover	1	
4	0255-60300	Right Cover Flapper	1	
5	0259-51700	Right Cover Up/Down Arm	1	
6	0290-50200	Side Flapper (Back Right)	1	
7	0312-77500	Flange Cap Nut M6 (Meck)	6	RH17M00070 ~
	0312-77500	Flange Cap Nut M6 (Meck)	4	~ RH17E00069
8	0347-51400	Foot Guard (R)	1	RH17M00070 ~
9	0348-50200	Right Cover CMP	1	
10	89-1137-060172	Hexagonal Bolt (PW) M6*17	4	
11	89-1253-080202	Flange Mini Hexagonal Bolt (8T) M8*20	1	
12	89-1561-080002	Mini Hexagonal U Nut M8	1	
13	89-1711-100002	Flat Washer 10*18*1.6	1	
14	89-1713-060002	Flat Washer 6 (large)	6	RH17M00070 ~
	89-1713-060002	Flat Washer 6 (large)	4	~ RH17E00069
15	89-1714-100002	Flat Washer 10	2	
16	89-1750-080002	Spring Washer 8	1	
17	89-2131-100002	Snap Pin 10	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0244-61800	Side Flapper (Front)	1	
2	0244-63900	Round Head Pin 10*72	2	
3	0347-54200	Rear Side Flapper (L)	1	RH18M00408 ~
	0255-60800	Rear Side Flapper (Left A)	1	~ RH18D00290
4	0312-77500	Flange Cap Nut M6 (Meck)	4	
5	0347-51300	Foot Guard (L)	1	RH17M00070 ~
6	0348-50300	Left Cover CMP	1	
7	83-1751-312-00	Washer 8*25*3.2	3	
8	89-1137-060172	Hexagonal Bolt (PW) M6*17	2	RH17M00070 ~
	89-1137-060172	Hexagonal Bolt (PW) M6*17	4	~ RH17E00069
9	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	3	
10	89-1671-080042	Mini Cap Nut M8	3	
11	89-1713-060002	Flat Washer 6 (large)	4	
12	89-1714-100002	Flat Washer 10	4	
13	89-2131-100002	Snap Pin 10	2	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1485-551-00	Driving Tension Spring	1	
2	0244-50600	Knife Brake	1	
3	0244-50710	Knife Brake Bracket CMP	1	
4	0244-61200	Rear Guard	1	
5	0244-61300	Rear Guard Flapper	1	
6	0244-61400	Rear Guard Flapper Holder	1	
7	0312-50700	Side Rear Flapper (L)	1	
8	0312-77500	Flange Cap Nut M6 (Meck)	2	
9	83-1565-329-00	Washer 13*22*2.3	4	
10	83-1751-312-00	Washer 8*25*3.2	3	
11	83-1754-329-00	Washer 13*22*1.0	2	
12	89-1137-060152	Hexagonal Bolt (PW) M6*15	2	
13	89-1137-060172	Hexagonal Bolt (PW) M6*17	4	
14	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	3	
15	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	3	
16	89-1581-060042	Flange Cap Nut M6	4	
17	89-1671-080042	Mini Cap Nut M8	3	
18	89-1713-060002	Flat Washer 6 (large)	2	
19	89-2120-200152	Split Pin 2*15	1	
20	89-2181-060162	Flat Head Pin 6*16	1	
21	89-2521-000100	E Type Ring 10	2	
22	89-3510-012200	DU Bush 12.20	2	

42/51

Cutting 5/6

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1483-818-00	Knife Collar	2	
2	80-1483-821-00	Knife	2	
3	0207-50200	Knife Setting Bolt M14*34	2	
4	0221-76100	Washer 12*40*6	1	
5	0244-51200	Knife Stay (R817B)	1	
6	0244-51600	Mini Hexagonal Bolt (8T) M14*30 (Knife Stay)	2	
7	0244-51800	Nut Guard 14	2	
8	0244-51900	Knife Bracket	1	
9	0244-52100	Knife Neck Guard	1	
10	0244-74600	Hard Lock Nut M14	2	
11	0312-50300	Knife Pulley CMP	1	
12	0312-51800	Washer Plate CMP	1	
13	0322-52200	Nipple Bolt M12*35 (8T)	1	
14	83-1415-975-00	Grease Nipple M6	1	
15	83-1483-175-00	Bag Nut M20 (Lock)	1	
16	89-1750-120002	Spring Washer 12	1	
17	89-1750-140002	Spring Washer 14	2	
18	89-1750-200002	Spring Washer 20	1	

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0262-50100	Dust Plate	1	
2	0322-52100	Vertical Shaft	1	
3	0322-72700	Oil Seal UE 35.62.6	1	
4	0347-50100	Safety Cover CMP	1	
5	89-2512-000620	Snap Ring (R62)	4	
6	89-3115-060074	Bearing 6007 2RS	2	
7	89-5121-406212	Oil Seal UE 40.62.12	1	

44/51 Seat 1/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1792-988-00	Harness Clip 8	1	
2	0207-72700	Gas Spring KMF 50-40	1	
3	0221-71900	Clip CT-339	1	
4	0244-22200	Seat Bracket Shaft	1	
5	0244-73700	Grommet 24	1	
6	0284-78100	Seat K4 (Black)	1	orec seat
7	0312-70700	Bonnet Clip	1	RH17M00070 ~
	0312-70400	Bonnet Clip	1	~ RH17E00069
8	0322-21600	Seat Bracket CMP	1	
9	0322-73100	Seat Cover (option)	1	orec seat
10	0341-21200	Lower Slide CMP	2	
11	0341-21300	Upper Slide CMP (R)	1	
12	0341-21400	Upper Slide CMP (L)	1	
13	0341-21500	Seat Lever Spring	1	
14	0341-21800	Slide Lever CMP	1	
15	83-1415-312-00	Washer 8*30*3.2	2	
16	89-1232-080202	Mini Hexagonal Bolt (SW) M8*20	2	
17	89-1233-080162	Mini Hexagonal Bolt (PWSW) M8*16	2	
18	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	6	
19	89-1543-080002	Mini Hexagonal Nut (SW) M8	2	
20	89-1553-060002	Bag Hexagonal U Nut M6	2	
21	89-1561-080002	Mini Hexagonal U Nut M8	1	
22	89-1561-100002	Mini Hexagonal U Nut M10	2	
23	89-1631-080042	Flange Mini Hexagonal Nut M8	4	
24	89-1711-080002	Flat Washer 8	1	
25	89-1711-100002	Flat Washer 10*18*1.6	4	
26	89-1750-080002	Spring Washer 8	2	
27	0348-24100	Upper Seat Receiver CMP	1	other seat
28	0348-71100	Seat (COBO)	1	RH18M00408 ~

45/51 Seat 2/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0207-72800	Switch Lock Nut	1	
2	0207-74400	Safety Switch K17850	1	
3	0207-72900	Seat Switch Spring	1	other seat
	0341-21700	Seat Switch Spring	1	orec seat
4	0312-22300	Rubber, Seat Spacer	2	
5	0341-21100	Seat Receiver	1	
6	0341-21600	Seat Switch Stay	1	
7	0348-21510	Clutch Cancellation Stay	1	RH17M00070 ~
	0348-21500	Clutch Cancellation Stay	1	~ RH17M00069
8	89-1137-060152	Hexagonal Bolt (PW) M6*15	2	
9	89-1137-060172	Hexagonal Bolt (PW) M6*17	2	RH17M00070 ~
10	89-1253-100202	Flange Mini Hexagonal Bolt (8T) M10*20	2	
11	89-1390-060162	Welded Bolt M6*16	1	
12	89-1531-060042	Flange Nut M6	3	
13	89-1561-100002	Mini Hexagonal U Nut M10	2	
14	89-1714-100002	Flat Washer 10	2	
15	89-1541-060002	Hexagonal Nut (SW) M6	2	~ RH17M00069

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0244-71200	Spring for Seat Link	2	
2	0312-21600	Parallel Seat Link CMP	1	
3	0312-21700	Seat Parallel Link (B)	2	
4	0312-21800	Spring Shaft	2	
5	0312-22100	Spring Shaft Hook CMP	1	
6	0329-80300	Seat Link Shield (RMK150)	2	
7	0348-21100	Link Upper Bracket (R) CMP	1	
8	0348-21200	Link Upper Bracket (L) CMP	1	
9	0348-21310	Link Upper Bracket CMP	1	RH17M00070 ~
	0348-21300	Link Upper Bracket CMP	1	~ RH17M00069
10	83-1020-363-00	Thrust Washer 16*24*1.0	12	
11	89-1211-100302	Mini Hexagonal Bolt M10*30	1	
12	89-1714-100002	Flat Washer 10	1	
13	89-2521-000120	E Type Ring 12	6	

47/51 Engine(Kawasaki) 1/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
-	0322-74000	Fuel Cock Assy (K)	1	Include : 1,5,11
-	0322-72500	Fuel Hose 270L & Clip	1	Include : 1,11
-	0322-72400	Fuel Hose 600L & Clip	1	Include : 1,10
-	0312-44100	Oil Drain Assy (K)	1	Include : 4,6,7,8,9,16
1	80-1483-988-00	Hose Clip 17	4	
2	80-1792-988-00	Harness Clip 8	1	
3	0207-74900	Copper Packing 12.5*19*1.0	1	
4	0244-40700	Drain Bolt (K)	1	
5	0244-74500	Fuel Cock	1	
6	0244-75700	Hose Band 22	1	
7	0271-73300	Socket	1	
8	0312-44200	Oil Drain Hose (K)	1	
9	0312-44300	Drain End CMP (K)	1	
10	0322-70400	Fuel Hose 600L	1	
11	0322-70500	Fuel Hose 270L	1	
12	89-1137-060122	Hexagonal Bolt (PW) M6*12	1	
13	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	1	
14	89-1251-120152	Flange Mini Hexagonal Bolt M12*15	1	
15	89-1581-060042	Flange Cap Nut M6	1	
16	89-5221-016000	O Ring P16	1	
17	0312-77300	Harness (K)	1	

48/51 Engine(Kawasaki) 2/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0312-40100	Muffler	1	
2	0312-40200	Exhaust Pipe CMP (FS641)	1	
3	0312-40500	Muffler Cover CMP	1	
4	0312-70500	Muffler Band	1	
5	0329-40600	Exhaust Pipe Cover (RMK150)	1	
6	89-1132-060122	Hexagonal Bolt (SW) M6*12	4	
7	89-1232-080202	Mini Hexagonal Bolt (SW) M8*20	2	
8	89-1233-080202	Mini Hexagonal Bolt (PWSW) M8*20	2	
9	89-1611-080042	Mini Hexagonal Nut M8	4	
10	89-1711-060002	Flat Washer 6	4	
11	89-1750-080002	Spring Washer 8	4	

49/51 Engine(Kawasaki) 3/3

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	80-1487-516-00	Washer 11*40*6	1	
2	0207-76300	Nut UNF 1/4	1	
3	0227-40500	Engine Pulley	1	
4	0244-41100	Engine Collar	1	
5	0244-41200	Sub Engine Collar (21HP)	1	
6	0312-42100	Hexagonal Bolt (8T) UNC 3/8-16*38	4	
7	83-1437-115-00	Hexagonal Bolt (8T) UNF7/16*35	1	
8	83-1493-300-00	Spring Washer 7/16	1	
9	89-1750-060002	Spring Washer 6	1	
10	89-1750-100002	Spring Washer 10	4	
11	89-1812-100002	Toothed washer (inside) 10	1	
12	89-6123-003202	V Belt SB-32 (W800)	1	
13	9025-0010	Kawasaki Engine FS691V-AG80	1	

51/51 Label 2/2

Ref.	Parts Number	Parts Name	Quantity	Remarks
1	0215-80400	Driving Clutch ON-OFF Label	1	
2	0215-83100	Attention Mark for Slope	1	
3	0215-83200	Label, Protection Equipment	1	
4	0217-70100	Label, Differential Lock (13168)	1	
5	0217-70800	Label, Gear Oil 1.0L	1	
6	0223-76100	Label, Caution (Large)	1	
7	0227-71200	Clinometer Label	1	
8	0227-71300	Label, Right Side (4WD)	1	
9	0227-71400	Label, Left Side (4WD)	1	
10	0244-80700	Label, Handle (Blue)	1	
11	0259-80600	Label, Caution for Engine Oil	1	
12	0259-80700	Label, Cutting Height Line	1	
13	0310-71300	Label, Noise 102db	1	
14	0312-76900	Label, OREC B05	1	
15	0312-86100	Label, Seat Spring Adjusting	1	
16	0312-86200	Label, Caution for HST Oil	1	
17	0322-77900	Reflection Seat (Red)	2	
18	0322-78300	Label, Fuse Box	1	
19	0322-78800	Label, OREC B03	2	
20	0329-76200	Label, Caution for Hand and Leg etc	2	
21	0329-77500	Label, Choke (RMK150)	1	
22	0329-78400	Label, Control (RMK150)	1	
23	0347-71300	Label, Maintenance & Belt Size	1	
24	0347-71400	Label, RM982F	1	
25	0347-76400	Label, Front (4WD)	1	
26	0347-79200	Label, Front Side Set	1	
27	0348-72400	Label, Cutting Height Adjusting	1	
28	80-1488-912-00	Label, Key (13121)	1	
29	80-1488-921-00	Label Pedal Stopper (13113)	1	
30	80-1488-928-10	Label, Caution for Belt Involving	1	
31	-	Serial Number	1	